



Acer Aspire 5253 Optical Drive Replacement

This guide will help replace the optical drive if there are any issues with it.

Written By: Cynthia Barajas





TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Battery



- Turn the laptop over.

Step 2



- "Unlock" your battery by moving the switch as shown so that an unlocked lock on a red background is shown.

Step 3



- Next move the other switch, while the unlocked symbol is still showing. The battery should pop up, and no longer be flush with the bottom of the laptop.

Step 4



- Now remove the battery by lifting it out of the laptop by the side closest to the switches.

Step 5



- You have successfully removed the battery. Congratulations!

Step 6 — Optical Drive



- Turn the computer over and locate the screw that is in between the battery and cover panel as shown in the picture.

Step 7



- Remove the screw with a Phillips #00 screw driver.
- ❗ The screw is 3/8" in length and has a 1/4" head.

Step 8



- Carefully pry the optical drive loose.

Step 9



- Slowly remove the optical drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 05:58:30 PM.